

# RCS64 Pitstops at WHO/digital

**Black Button**

**Enter pits** press and hold black lane changer button prior to pit entry. Car enters pit lane.

**Pit entry registered** when car passes pit tower, RCS64 knows car is in pit.

**Red Button**

**Stop in pits** cruise to a halt in pit box or press red brake button to come to a precise halt.

**Black Button**

**Bring up Pit Menu** press and hold black lane change Button to bring up pit menu.

**Black Button**

**Scroll Pit Menu** tap black button to Scroll through fuel fill and tyre options.

**Red Button**

**Re-fuel** tap red brake button on refuel icon to start refuel process. Green bar fills up.

**Change Tyres** tap red brake button on Hard, Soft, Inter or Wet icon. Green bar fills up.

**Red Button**

**Leave pits** when green tyre bar is at 100%, the car is ready to leave. Fuel does not need to be at 100% (splash & dash). Sometimes there is a delay on release - as in real racing. The exit sensor notifies RCS64.


**Red 'Brake' button**

- Stops car in pits
- 'Select' button in pit menu

**Black 'Lane Change' button**

- Press & hold brings up pit menu
- Scrolls through options in pit menu

A video of the pitstop process is available on the WHO website & YouTube



**GO! GO GO!**